



\* For footing depth greater than 1520 mm add 0.75 times that portion of depth that exceeds 1060 mm to allow for excavation face slope. i.e., 2500 mm depth  $(2500 - 1060)(0.75) = 1080 + 3000 = 4080$  mm

Footing Excavation